



KIT BAG CONTENTS

- 17 1¹/₄" x ³/₈" BOLTS
- 2 2¹/₂ " x ³/₈" BOLTS
- **19 ¾" LOCK NUTS**
- 4 3/8" WASHERS
- 14 ³/₄" SELF-TAPPING **SCREWS**
- 4 LADDER END CAPS

6X10 - 5 FT STAND **INSULATED BLIND**

· Set blind on a level surface, pull out all legs to settle the blind into it's final position

·Raise platform and install five 3/8" bolts, level platform by setting equal gap between

- Attached ladder to platform using 3" x 3/8 bolts. Be sure to install bolt threads towards