

LEGS ARE MARKED AND INSTALLED WITH THE LEG NUMBER ON THE LEG AND BASE

KIT BAG CONTENTS

28 - 1¹/₄" x ³/₈" BOLTS

2 - 21/2" x 3/8" BOLTS

30 - 3/8" LOCK NUTS

4 - 3/8" WASHERS

24 - ³/₄" SELF-TAPPING **SCREWS**

4 - LADDER END CAPS

6X6 - 15 FT STAND **INSULATED BLIND**

Raise blind and slide in legs, make sure legs are in all the way, tighten T-Handle

· Set blind on a level surface, pull out all legs to settle the blind into it's final position

· Raise platform and install five 3/8" bolts, level platform by setting equal gap between

- Install 43" braces from Leg One and Leg Two to platform using 3/8 bolts and lock nuts - Attached ladder to platform using 2 1/2" x 3/8 bolts. Be sure to install bolt threads towards