

KIT BAG CONTENTS

21 - 1¼" x 3%" BOLTS

2 - 2½" x ¾" BOLTS

23 - %" LOCK NUTS

4 - 3/8" WASHERS

12 - ¾" SELF-TAPPING SCREWS

4 - LADDER END CAPS

6X8 - 10 FT STAND INSULATED BLIND

Raise blind and slide in legs, make sure legs are in all the way, tighten T-Handle

- ·Lower to 2" off the ground
- · Install all braces, leave 3/8 bolts and lock nuts loose at this time
- ·Set blind on a level surface, pull out all legs to settle the blind into it's final position
- · Tighten all bolts
- ·Raise platform and install five 3/8" bolts, level platform by setting equal gap between vertical railing and the blind.
- Install 43" braces from Leg One and Leg Two to platform using 3/8 bolts and lock nuts
- Attached ladder to platform using 2 1/2" x 3/8 bolts. Be sure to install bolt threads towards the outside, this keeps bolts from creating a tripping hazard.
- Install left and right ladder hand rails with 3/4" self-tapping screws
- Push in plastic ladder end caps on each end of the ladder rails